

Cold weather got you down?



Get your EdenPURE heater today:

- Shave money off your heating bill
- Unit is cool to touch
- Advanced quartz infrared technology so unit doesn't reach unsafe temperatures
- Doesn't reduce humidity or oxygen levels in your home
- Heats evenly wall to wall, floor to ceiling



Check out www.trucnrv.com for more EdenPURE products!

Upcoming Events

Geauga County Fair	Burton, OH	September 3rd -7th
Best of Fall Home Show	Ohio Expo Center Columbus, OH	September 11th -13th

Car & Truck 16-Point Inspection Lube & Oil Change- 5 qts, \$24.95*

**RVs slightly higher, synthetic extra*

- | | |
|------------------|--------------------------|
| Check all belts | Check all lights |
| Check all fluids | Check anti-freeze |
| Check brakes | Check air conditioner |
| Check wipers | Check tires and pressure |
| Grease all doors | |

Winterize
 Your RV
 \$69.95

Winterization Procedure

1. Make sure the black & gray water tanks have been dumped and valves are open, drain cap off.
2. Drain water from fresh water holding tank and water heater tank (it's necessary to remove water heater plug and open the pressure relief valve to drain this tank). Open the low point drain valves in the fresh water lines. When the drains stop running, close them.
3. Screw a blow out plug into the city water fitting on the outside of the unit.
4. Apply lo-psi compressed air to the blow out plug.
5. The hot water faucets also need to be blown out (kitchen sink, bath sink, shower) Beginning with the faucet furthest from the fresh water tank, open the hot water faucet valve and let run until no water comes out, then close valve.
6. Repeat step 5 for the other hot water valves (in order of furthest from fresh water tank first)
7. Repeat steps 5 and 6 for the cold water faucet valves. In addition you must also blow out the toilet water valve.
8. Remove air from the city water hook up. Make sure that all faucets are turned off. Close all low spot water drain valves and reinstall water heater drain plug. Disconnect the tubing from the inlet side of the water pump. Fit on end of a six foot section of 1/2" water tubing over the barb and immerse the other end in your container of non-toxic RV anti-freeze. Turn on coach water pump.
9. Beginning with the cold water faucet valve closest to the fresh water tank, open the valve until the pink anti-freeze just begins to come out. Repeat this for all other cold water faucet valves (be sure to remember the toilet valve).
10. Pour the remaining 1/3 gallon of anti-freeze into the drains of the kitchen, bath and shower to protect traps from freezing.
11. Fully charge coach battery and disconnect negative (-) cable.

RE M I N D E R:

We sell & install

- Truck Caps
 - Tonneau Covers
 - Hitches
 - Bug Guards
- AND MORE